

Bench w/ Back Series

model no:

GV420G

6' BENCH, SURFACE MOUNT
PolyTuf® Plastic lumber Custom-Extruded

customer service:

ASSEMBLERS: If you find any parts missing or damaged, or if you're having difficulty assembling your furniture/equipment, call us at:

* Before calling, have your product model number available.

1-800-253-8619 (Inside U.S.A.)
260-352-2102 (Outside U.S.A.)
Monday thru Friday,
8:00 AM - 4:30 PM Eastern Time
(EXCEPT HOLIDAYS)

maintenance:

Regular inspection and maintenance of all parts, and fasteners is necessary. Tighten all bolts and nuts. Inspect Tops, Seats, Legs, Braces and Fasteners periodically for wear or vandalism. Replace broken or worn parts immediately or take equipment out of service until repairs are made. Use genuine Green Valley replacement parts.

KEEP THIS ASSEMBLY/SPECIFICATION SHEET FOR FUTURE REFERENCE.

specifications:

NOTE: We reserve the right to change specifications without notice.

Framework assemblies are finished with powder coating; electrostatically applied and oven cured according to powder manufacturer's specifications. Fasteners are stainless steel to resist corrosion.

BENCH LEGS:

Main supports are constructed of 2 7/8" od x 12 gage structural steel tubing. Attach tubes are constructed of 2 3/8" od x 12 gage and 2 7/8" od x 12 gage structural steel tubing. Mounting brackets on legs are 10 gage sheet steel. The mounting plate covers are 2 piece cast aluminum.

BENCH:

The bench's frame panel is constructed of 10 gage formed sheet steel and mounting brackets of 10 gage sheet steel. The planks are made of PolyTuf® Plastic lumber consisting of recycled plastic.

GENERAL:

6' Surface Mount Bench ground space requirements are 26 1/2" x 79 1/2". The seat is 72" long x 23 3/8" wide and 17 3/4" to the top of the seat.

PolyTuf HDPE plastic lumber is custom-extruded from purified blends of recycle plastics – the kind that come from milk and detergent bottles. PolyTuf plastic lumber is well suited for exterior applications where resistance to weathering and minimal maintenance is required, and a quality appearance is essential. PolyTuf maintains its color stability and finish over its entire service life, and never needs to be sealed, painted or stained.

AAMA 2604-05 Certification

Our seven-step powder-coat system exceeds AAMA 2604-05 (American Architectural Manufacturers Association) test specifications—one of the highest in the industry. Our coating stood up to some of the toughest test specifications, including adhesion, abrasion resistance, chemical resistance, corrosion resistance and fade resistance, to ensure that our products will last longer than anyone else's.

AAMA 2604-05 test Procedures and Performance Requirements

| Test Requirements | Compliance |
|--|------------|
| Salt-Spray Resistance: 3,000 hours per ASTM B 117 | Yes |
| Weathering: Color Retention, 5-year south Florida sun, per ASTM D 2244 with a maximum 5deltaE change | Yes |
| Weathering: Chalk resistance, 5-year south Florida sun, per ASTM D 4214 with a max rating of 8 | Yes |
| Weathering: Gloss Retention, 5-year south Florida sun, per ASTM D 523 with a min of 30% | Yes |
| Weathering: Resistance to Erosion, 5-year south Florida sun, with less than 10% film loss | Yes |
| Chemical Resistance: Muriatic Acid, Mortar, Nitric Acid, Detergent and Window Cleaner | Yes |
| Dry Film Hardness per ASTM D 3363 with no rupture | Yes |
| Adhesion: Dry Adhesion, Wet Adhesion and Boiling Water Adhesion using the cross hatch method with 0% failure | Yes |

Seven Steps to Long-Lasting Furniture: Our Superior Powder-Coating Process

What's responsible for the good looks and durability of all our products? Our seven-step powder-coating process, which is unlike any other in the industry. While other companies also offer powder-coated products, our seven-step process ensures the highest quality and longevity for our products.

STEP 1—Shot-Blasting to White Metal

First, all of our metal is cleaned to white metal. We strip it to its purest form using our state-of-the-art shot-blast system. This process removes all the impurities from the metal, especially at the weld joints. It's more effective than traditional acid cleaning and also creates a more textured surface, allowing for better adhesion of the powder coat.

STEP 2—Five-Stage Chemical Pre-Treatment

Next, the metal goes through a five-stage chemical pre-treatment cleaning process. It is etched, rinsed and cleaned to eliminate any residue, then it's sealed—further promoting adhesion and encouraging corrosion prevention.

STEP 3—Pre-Heating

Prior to coating, the part is pre-heated so that it can be dried, warmed and then sent directly to the spray booth. With the part heated, it draws powder into the joints, corners and hard-to-reach places to ensure complete coating of the entire surface.

STEP 4—Zinc-Rich Epoxy Coating

After the pre-heating, a Zinc-Rich epoxy powder-coating is applied to provide the highest quality of corrosion control. It works as a prime coat to protect the metal from corrosion before it receives its topcoat.

STEP 5—Zinc-Rich Epoxy Coating Gel-Cure

Next, the Zinc-Rich epoxy coating is cured to a gel, allowing the polyester topcoat to combine with the Zinc-Rich epoxy, promoting better adhesion.

STEP 6—AAMA 2604-Compliant Polyester Topcoat

A polyester topcoat is then applied that's specially formulated to meet AAMA 2604 standards for fading, cracking, chalking, gloss retention, erosion resistance and chemical resistance. No one else in the industry uses this high standard of topcoat. It ensures that our products will maintain their beauty and durability for years to come.

STEP 7—Final Cure

Finally, the metal goes through a cure oven, which hardens the topcoat and completes the integrated bonding between the Zinc-Rich epoxy and AAMA 2604-Compliant Polyester Topcoat.

assembly procedures: IMPORTANT: Assemblers should be reasonably skilled in the assembly of commercial grade/heavy duty fabricated steel equipment.

To ensure proper assembly, it is suggested that you take adequate time to locate and identify each part. To prevent scratching of the finished pieces, we recommend this unit to be assembled on a clean, flat, solid, surface with a drop cloth, allowing plenty of working room. Also please read the instructions and study the sketches very carefully. A little extra time spent before assembly will be well worth it in performing a complete, proper assembly. Please note that all parts have been pre-cut and pre-drilled.

During the assembly process leave all bolts and nuts "finger tight", until the entire unit is completely assembled. This allows room for movement to level or adjust all seats, tops, benches, framework and braces if necessary. After final adjustment and leveling, permanently tighten all nuts, bolts and fasteners.

7L

STEP 1

Stand both right and left surface mount legs (7022, 23) approximately the distance of the attached tubes (7413) apart, so that the surface mount legs are on the floor with the round sleeves on each leg facing inward. Take the ends of each attach tube and insert into the round sleeves of each leg. The leg and attach tube assembly is representative of illustration below.

STEP 2


Position 16294 bench above legs and lower bench aligning the mounting brackets on each leg to the inside of the bench seat on each end. It may be necessary to push leg inward to bring mounting brackets on leg and bench in order to bolt them together. Use two 5/16" x 1 1/2" hex head bolts with two 3/8" flat washers, one 5/16" nut and one 5/16" split washer per each bolt.

STEP 3

Assemble Surface Mount Plates (7256) to each leg. Level bench and tighten all fasteners with proper tools.

STEP 4

It is suggested that you place the unit in its chosen location, then mark the hole openings of the base plates. Place the foundation securement hardware in the marked areas. This allows you a more accurate and secured placement. When the foundation securement hardware has been installed, place the unit in its new location and secure to the foundation.



STEP 5

Place cover halves around leg and secure together with two 1/4" x 1/2" machine screws. Draw screws to a snug fit taking care not to over tighten.

installation: WARNING: The proper installation for Green Valley products may depend upon many factors unique to the site, location, or use of a particular product. Consult with your contractor or other professional to determine your specific installation requirements.

product dimensions:

