

model no:

CM305Q, CM310Q
CM302N



WABASH VALLEY

CAMINO SERIES

CAFE, DINING, CHAIR
CAMINO

© Wabash Valley Manufacturing, Inc.

customer service:

ASSEMBLERS: If you find any parts missing or damaged, or if you're having difficulty assembling your furniture/equipment, call us at:

* Before calling, have your product model number available.

1-800-253-8619 (Inside U.S.A.)
260-352-2102 (Outside U.S.A.)
Monday thru Friday,
8:00 AM - 4:30 PM Eastern Time
(EXCEPT HOLIDAYS)

Any correspondence concerning our product should be sent directly to our Customer Service Manager at:

Wabash Valley Manufacturing, Inc.
505 E. Main Street
P.O.Box 5
Silver Lake, IN 46982 U.S.A.
FAX: 260-352-2160

maintenance:

Regular inspection and maintenance of all parts, and fasteners is necessary. Tighten all bolts and nuts. Inspect Tops, Seats, Legs, Braces and Fasteners periodically for wear or vandalism. Replace broken or worn parts immediately or take equipment out of service until repairs are made. Use genuine Wabash Valley replacement parts.

To restore plastisol coating to its luster after prolonged use, wash/rinse/dry and use Armor-All ® or similar quality vinyl protectant.

KEEP THIS ASSEMBLY/SPECIFICATION SHEET FOR FUTURE REFERENCE.

specifications:

NOTE: We reserve the right to change specifications without notice.

Heat fused poly-vinyl coating, finished on inner-metal structure, to an approximate 3/16" thickness. Framework assemblies are finished with powder coating; electrostatically applied and oven cured according to powder manufacturer's specifications. Fasteners are stainless steel to resist corrosion.

CHAIR FRAME:

Main supports are constructed of 1 1/4" od x 16 gage 6063-T52 aluminum tubing. Back is reinforced with 1/2" diameter 6063-T52 aluminum rod. The chair's mounting brackets are constructed of 3/8" thick aluminum sheet. CM302N main supports are constructed of 1" od x 14 gage 6061-T6 aluminum tubing.

SEAT:

Seats 12 gage sheet steel for the square perforated pattern. The seat's framing is 1/8" x 1 1/4" strip steel. The seat's support brace and mounting brackets are 1/4" x 1" steel flat bar.





CM302N seat and back consists of molded polypropylene plastic. The chair is assembled with stainless steel hardware.

GENERAL:


CM305Q overall height of chair back is 34 1/8" and width is 15 5/8". Seat is 16 3/8" in diameter and 17 1/2" to top of the seat. Legs are adjustable for leveling purposes. CM310Q ground space requirements are 21 1/2" x 36". The seat is 17 3/4" wide x 28 1/4" long and 18 1/8" to the top of seat.

CM302N ground space requirements are 22 7/8" x 23 1/2". The seat is 18 1/2" wide x 18 3/8" deep and 18 1/2" to the top of seat.

parts identification:



REPLACEMENT PART








#19068

ADJUSTABLE SWIVEL GLIDE

ITEM	PART#	DESCRIPTION	QTY
A1	8089	16" ROUND CAMINO SEAT	1
A2	8158	SQ. PERFORATED ATTACHED CHAIR	1
B1	7064	CAFE CHAIR LEG ASSEMBLY	1
B2	7169	DINING CHAIR LEG	1

hardware identification:



HARDWARE PACKAGE NUMBER			21016A	21014
ITEM	PART#	DESCRIPTION	QTY	QTY
C	17012	5/16-18 x 2" HEX HEAD BOLT - SS	2	0
D	17028	3/8" FLAT WASHER - SS	4	8
E	17032	5/16-18 HEX FINISH NUT - SS	2	4
F	17011	5/16-18 x 1 1/2" HEX HEAD BOLT - SS	0	4
G	17050	5/16" SPLIT LOCK WASHER - SS	2	4



ASSEMBLY TOOLS REQUIRED

2 - 1/2" WRENCHES

assembly procedures: IMPORTANT: Assemblers should be reasonably skilled in the assembly of commercial grade/heavy duty fabricated steel equipment.

To ensure proper assembly, it is suggested that you take adequate time to locate and identify each part. To prevent scratching of the finished pieces, we recommend this unit to be assembled on a clean, flat, solid, surface with a drop cloth, allowing plenty of working room. Also please read the instructions and study the sketches very carefully. A little extra time spent before assembly will be well worth it in performing a complete, proper assembly. Please note that all parts have been pre-cut and pre-drilled.

During the assembly process leave all bolts and nuts "finger tight", until the entire unit is completely assembled. This allows room for movement to level or adjust all seats, tops, benches, framework and braces if necessary. After final adjustment and leveling, permanently tighten all nuts, bolts and fasteners.

76

CAFE CHAIR

STEP 1

Place (A1) 16" round seat atop (B1) cafe chair leg assembly. Align holes in (A1) seat mounting bracket with holes in (B1) leg assembly.

STEP 2

Thread one (D) flat washer onto one (C) hex bolt and slip into hole from side of (A1) through hole in seat. Add another (D) flat washer and one (G) lock washer and secure with (E) flanged hex nut, see Fig. 1.



STEP 3

Center (A1) seat with (B1) leg assembly and draw fasteners to a snug fit, both sides.

DINING CHAIR

STEP 1

Bring the (A2) attached chair down over the (B2) dining chair leg assembly, see FIG. 2. Attach the seat using four (F), (E), two (D) and one (G) per each side of the seat.



installation: WARNING: The proper installation for Wabash Valley products may depend upon many factors unique to the site, location, or use of a particular product. Consult with your contractor or other professional to determine your specific installation requirements.

product dimensions:

