## model no:

CN400D, CN400P, CN400R, CN400S,

CN405D, CN405P, CN405R, CN405S,

CN420D, CN420P, CN420R, CN420S,

CN425D, CN425P, CN425R, CN425S,

SP405P, SP405R

## CONTEMPORARY SERIES

4' & 6' CONTEMPORARY BENCH & LOW PROFILE EXPANDED METAL, PERFORATED, RIB, & SLAT PORTABLE & SURFACE MOUNT

## customer service:

ASSEMBLERS: If you find any parts missing or damaged, or if you're having difficulty assembling your furniture/equipment, call us at:

\* Before calling, have your product model number available.

1-800-253-8619 (Inside U.S.A.) 260-352-2102 (Outside U.S.A.) Monday thru Friday, 8:00 AM - 4:30 PM Eastern Time (EXCEPT HOLIDAYS)

### maintenance:

Regular inspection and maintenance of all parts, and fasteners is necessary. Tighten all bolts and nuts. Inspect Tops, Seats, Legs, Braces and Fasteners periodically for wear or vandalism. Replace broken or worn parts immediately or take equipment out of service until repairs are made. Use genuine Wabash Valley replacement parts.

To restore plastisol coating to its luster after prolonged use, wash/rinse/dry and use Armor-All ® or similiar quality vinyl protectant.

KEEP THIS ASSEMBLY/SPECIFICATION SHEET FOR FUTURE REFERENCE.

## specifications:

NOTE: We reserve the right to change specifications without notice.

Heat fused poly—vinyl coating, finished on inner—metal structure, to an approximate 3/16" thickness. Framework assemblies are finished with powder coating; electrostatically applied and oven cured according to powder manufacturer's specifications. Fasteners are stainless steel to resist corrosion.

#### BENCH FRAME:

Main supports are constructed of 2 7/8" od x 12 gage galvanized steel tubing. Attach tubes are constructed of 2 3/8" od x 12 gage tubing. Both types of tubing are made from galvanized structural steel tubing. Mounting brackets on the legs are 10 gage sheet steel and 1/4" x 1 1/2" flat bar steel. The mounting plate covers are made of 2 piece cast aluminum. The surface mount screw—in attachments are made of steel plate 1/4" x 6" with a 5/8" threaded stud.

#### BENCH SEAT


Expanded metal seat uses 3/4" #9 expanded steel. Rib seats use 10 gage and perforated seats use 12 gage sheet steel. Slats are 3/16" x 2 1/4" flat bar. The bench's frame/mounting brackets are made from 10 gage sheet steel. Support braces, adding support to the bench's rolled—sides, are 1/4" x 1 1/4" flat bar steel.


#### **GENERAL:**

- 4' Contemporary Bench ground space requirements are 27 1/2" x 59". The bench seat is 48 1/8" long x 26 1/4" wide and 15 1/2" to the top of the lowest part in the bench's seat. 4' low profile bench ground space requirements are 30 3/8" x 59". The bench seat is 48 1/8" long x 30 3/8" wide and 16 1/2" to the top of the seat.
- 6' Contemporary Bench ground space requirements are 27 1/2" x 83". The bench seat is 72 1/8" long x 26 1/4" wide and 15 1/2" to the top of the lowest part in the bench's seat. 6' low profile bench ground space requirements are 30 3/8" x 83". The bench seat is 72 1/8" long x 30 3/8" wide and 16 1/2" to the top of the seat.

The Memorial Plaque consists of 304 brushed stainless steel.

Al146 page 1





# $assembly \ \ procedures: \ \ {}^{\text{IMPORTANT: Assemblers should be reasonably skilled in the assembly of commercial grade/heavy duty fabricated steel equipment.}$

To ensure proper assembly, it is suggested that you take adequate time to locate and identify each part. To prevent scratching of the finished pieces, we recommend this unit to be assembled on a clean, flat, solid, surface with a drop cloth, allowing plenty of working room. Also please read the instructions and study the sketches very carefully. A little extra time spent before assembly will be well worth it in performing a complete, proper assembly. Please note that all parts have been precut and pre-drilled.

During the assembly process leave all bolts and nuts "finger tight", until the entire unit is completely assembled. This allows room for movement to level or adjust all seats, tops, benches, framework and braces if necessary.

After final adjustment and leveling, permanently tighten all nuts, bolts and fasteners.

#### STEP 1

Free stand both right and left legs (C-) and place them approximately the distance of the attached tubes apart, with the round sleeves on each leg facing inward. Take the ends of each attach tube and insert into the round sleeves on each leg, see FIG. 1.

#### STEP 2

Rotate assembly (C-) upside down, attach the screw in attachments (E1), see FIG. 2. After all parts have been secured, rotate the bench to it's upright position.

#### STEP 3

Take the (A-/B-) bench seat and raise it above the bench's frame. Bring the bench seat down, aligning the mounting bracket, on each leg to the inside of the bench seat on each end, see FIG. 3.


NOTE: It may be necessary to push/pull each leg inward/outward to bring mounting bracket, on each leg, as close as possible to the inside of the bench seat on each end.


#### STEP 4

Align the holes on the ends of the bench seat, with the holes on the mounting bracket of each leg. Insert (E) screw and (G) nut, with two (F) and one (L) for each screw, into all holes.

#### STEP 5

Adjust the bench seat by pushing the top of the bench downward, in a rocking motion, while raising the front of the bench upward, to its most forward position. Draw the fasteners to a snug fit with wrenches, see FIG. 3.





installation: WARNING: The proper installation for Wabash Valley products may depend upon many factors unique to the site, location, or use of a particular product. Consult with your contractor or other professional to determine your specific installation requirements.

AI146N

# assembly procedures, cont'd:


STEP 6


Level bench if necessary and tighten all fasteners with wrenches. If mounting plate covers (E2) are used place them around legs and secure with 2 (H) screws, see FIG. 6. Bring the screws to a snug fit being careful not to over tighten.

NOTE: THESE INSTRUCTIONS ARE FOR BOTH THE LOW PROFILE AND CONTEMPORARY BENCHES.

#### MEMORIAL BENCH INSTRUCTIONS

After engraving is complete, assemble plaque (E3) to the bench using four (J) and one (K) per each machine screw, see Fig. 7. Thread plaque between center bracket and window of bench panel. Align holes, insert screws and tighten.





# product dimensions:

